Nikon° D3200°

DUMMES

Learn to:

- Use the best settings for the kind of photos you want to take
- Adjust manual settings for better results with exposure, lighting, focus, and color
- Download, edit, and share your photos

IN FULL COLOR!

Julie Adair King

Author of Digital Photography For Dummies



Nikon[®] D3200[™] For Dummies[®]

Visit

www.dummies.com/cheatsheet/nikond3200 to view this book's cheat sheet.

Table of Contents

<u>Introduction</u>

A Quick Look at What's Ahead

Part I: Fast Track to Super Snaps
Part II: Working with Picture Files

Part III: Taking Creative Control

Part IV: The Part of Tens

Icons and Other Stuff to Note

eCheat Sheet
Practice, Be Patient, and Have Fun!

Part I: Fast Track to Super Snaps

1: Getting the Lay of the Land

Getting Comfortable with Your Lens

Attaching a lens Removing a lens Setting the focus mode (auto or manual)
Zooming in and out
Using a VR (Vibration Reduction) lens

Adjusting the Viewfinder Focus
Working with Memory Cards
Exploring External Camera Controls

Topside controls
Back-of-the-body controls
Front-left buttons
Front-right features
Hidden connections

Ordering from Camera Menus

<u>Using the guided menus</u> <u>Ordering off the main menus</u>

Monitoring Shooting Settings
Changing Settings Using the Information
Display
Displaying Help Screens
Customizing Your Camera: Setup Menu
Options
Restoring Default Settings

2: Choosing Basic Picture Settings

<u>Choosing an Exposure Mode</u> <u>Choosing the Release Mode</u> Single Frame and Quiet Shutter Release modes
Continuous (burst mode) shooting
Self-timer shooting
Wireless remote-control modes

Adding Flash

Enabling flash
Setting the Flash mode

Choosing the Right Quality Settings

<u>Diagnosing quality problems</u>
<u>Considering image size: How many pixels</u>
<u>are enough?</u>
<u>Understanding Image Quality options</u>
(<u>JPEG or Raw</u>)
<u>My take: Choose JPEG Fine or Raw (NEF)</u>

Setting Image Size and Quality

3: Taking Great Pictures, Automatically

Setting Up for Automatic Success
As Easy As It Gets: Auto and Auto Flash Off
Taking Advantage of Scene Modes
Getting More Creative with Guide Mode

4: Exploring Live View Photography and Movie Making

Using Your Monitor as a Viewfinder

<u>Live View safety tips</u> <u>Customizing the Live View display</u>

Focusing in Live View Mode

Choosing the right focusing pairs
Autofocusing in Live View and Movie
mode
Manual focusing for Live View and movie
photography

Shooting Still Pictures in Live View Mode Shooting Digital Movies

Choosing the video mode (NTSC or PAL)
Setting video quality (frame size, frame rate, and bit rate)
Controlling audio
Manipulating movie exposure
Reviewing a few final recording options
Recording a movie

Screening Your Movies
Trimming Movies
Saving a Movie Frame as a Still Image

Part II: Working with Picture Files

<u>5: Playback Mode: Viewing, Erasing, and Protecting Photos</u>

<u>Customizing Basic Playback Options</u>

Adjusting playback timing
Adjusting and disabling instant image
review
Enabling automatic picture rotation

<u>Viewing Images in Playback Mode</u>

Viewing multiple images at a time (thumbnails view)
Displaying photos in Calendar view
Choosing which images to view
Zooming in for a closer view

Viewing Picture Data

File Information mode
Highlights display mode
RGB Histogram mode
Shooting Data display mode
GPS Data mode
Overview Data mode

Deleting Photos and Movies

Deleting files one at a time

Deleting all photos and movies

Deleting a batch of selected files

Protecting Photos and Movies
Creating a Digital Slide Show
Viewing Your Photos and Movies on a
Television

6: Downloading, Printing, and Sharing Your Photos

Choosing the Right Photo Software

Three free photo programs

Advanced photo programs

Sending Pictures to the Computer

Connecting the camera and computer for picture download
Starting the transfer process
Downloading using ViewNX 2

Processing Raw (NEF) Files

<u>Processing Raw images in the camera</u> <u>Processing Raw files in ViewNX 2</u>

Planning for Perfect Prints

Check the pixel count before you print Allow for different print proportions

Get print and monitor colors in sync

<u>Preparing Pictures for E-Mail and Online</u> <u>Sharing</u>

<u>Prepping online photos using ViewNX 2</u> <u>Resizing pictures from the Playback menu</u>

Part III: Taking Creative Control

7: Getting Creative with Exposure

<u>Introducing the Exposure Trio: Shutter Speed,</u>
<u>Aperture, and ISO</u>

<u>Understanding exposure-setting side</u>
<u>effects</u>
<u>Doing the exposure balancing act</u>

Exploring the Advanced Exposure Modes
Reading the Meter
Setting Aperture, Shutter Speed, and ISO

Adjusting aperture and shutter speed Controlling ISO

<u>Choosing an Exposure Metering Mode</u> <u>Sorting Through Your Camera's Exposure-</u> Correction Tools

<u>Applying Exposure Compensation</u>
<u>Using autoexposure lock</u>
<u>Expanding tonal range with Active D-Lighting</u>

<u>Investigating Advanced Flash Options</u>

Choosing the right Flash mode
Adjusting flash output
Controlling flash output manually

8: Manipulating Focus and Color

Mastering the Autofocus System

Reviewing autofocus basics
Understanding the AF-Area mode setting
Changing the Focus mode setting
Choosing the right autofocus combo
Using autofocus lock

Focusing Manually
Manipulating Depth of Field
Controlling Color

Correcting colors with white balance Changing the White Balance setting Fine-tuning White Balance settings Creating white balance presets

<u>Choosing a Color Space: sRGB versus Adobe</u>
<u>RGB</u>
Taking a Quick Look at Picture Controls

9: Putting It All Together

Recapping Basic Picture Settings Shooting Still Portraits

<u>Capturing action</u>
<u>Capturing scenic vistas</u>
<u>Capturing dynamic close-ups</u>

Part IV: The Part of Tens

10: Ten Fun and Practical Retouch Menu Features

Applying the Retouch Menu Filters

Removing Red-Eye
Straightening Tilting Horizon Lines
Removing (Or Creating) Lens Distortion
Correcting Perspective
Cropping (Trimming) Your Photo
Shadow Recovery with D-Lighting
Boosting Shadows, Contrast, and Saturation
Together
Two Ways to Make Subtle Color Adjustments

<u>Applying digital lens filters</u> <u>Manipulating color balance</u>

<u>Creating Monochrome Photos</u>

11: Ten Special-Purpose Features to Explore on a Rainy Day

Annotate Your Images
Creating Custom Image Folders
Changing the Function Button's Function
Customizing the AE-L/AF-L Button
Using the Shutter Button to Lock Exposure
and Focus
Adding a Starburst Effect
Creating Color Effects

<u>Creating a color outline</u>
<u>Producing a color sketch</u>
<u>Playing with the Selective Color Filter</u>

Softening Focus for a Dreamy Effect Creating a Miniature Effect

Combining Two Photos with Image Overlay Cheat Sheet

Nikon® D3200™ For Dummies® by Julie Adair King



John Wiley & Sons, Inc.

Nikon® D3200TM For Dummies®

Published by John Wiley & Sons, Inc. 111 River Street Hoboken, NJ 07030-5774

www.wiley.com

Copyright © 2012 by John Wiley & Sons, Inc., Hoboken, New Jersey

Published by John Wiley & Sons, Inc., Hoboken, New Jersey

Published simultaneously in Canada

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, scanning or otherwise, except as permitted under Sections 107 or 108 of the 1976 United States Copyright Act, without either the prior written permission of the Publisher, or authorization through payment of the appropriate per-copy fee to the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, (978) 750-8400, fax (978) 646-8600. Requests to the Publisher for permission should be addressed to the Permissions Department, John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, (201) 748-6011, fax (201) 748-6008, or online at http://www.wiley.com/go/permissions.

Trademarks: Wiley, the Wiley logo, For Dummies, the Dummies Man logo, A Reference for the Rest of Us!, The Dummies Way, Dummies Daily, The Fun and Easy Way, Dummies.com, Making Everything Easier, and related trade dress are trademarks or registered trademarks of John Wiley & Sons, Inc. and/or its affiliates in the United

States and other countries, and may not be used without written permission. Nikon and D3200 are trademarks of Nikon Corporation. All other trademarks are the property of their respective owners. John Wiley & Sons, Inc. is not associated with any product or vendor mentioned in this book.

Limit of Liability/Disclaimer of Warranty: The publisher and the author make no representations or warranties with respect to the accuracy or completeness of the contents of this work and specifically disclaim all warranties, including without limitation warranties of fitness for a particular purpose. No warranty may be created or extended by sales or promotional materials. The advice and strategies contained herein may not be suitable for every situation. This work is sold with the understanding that the publisher is not engaged in rendering legal, accounting, or other professional services. If professional assistance is required, the services of a competent professional person should be sought. Neither the publisher nor the author shall be liable for damages arising herefrom. The fact that an organization or Website is referred to in this work as a citation and/or a potential source of further information does not mean that the author or the publisher endorses the information the organization or Website may provide or recommendations it may make. Further, readers should be aware that Internet Websites listed in this work may have changed or disappeared between when this work was written and when it is read.

For general information on our other products and services, please contact our Customer Care Department within the U.S. at 877-762-2974, outside the U.S. at 317-572-3993, or fax 317-572-4002.

For technical support, please visit www.wiley.com/techsupport.

Wiley publishes in a variety of print and electronic formats and by print-on-demand. Some material included with standard print versions of this book may not be included in e-books or in print-on-demand. If this book refers to media such as a CD or DVD that is not included in the version you purchased, you may download this material at http://booksupport.wiley.com. For more information about Wiley products, visit www.wiley.com.

Library of Congress Control Number: 2012943022

ISBN 978-1-118-44683-6 (pbk); ISBN 978-1-118-44678-2 (ebk); ISBN 978-1-118-44680-5 (ebk); ISBN 978-1-118-44682-9 (ebk)

Manufactured in the United States of America

10987654321



About the Author

Julie Adair King is the author of many books about digital photography and imaging, including the best-selling Digital Photography For Dummies. Her most recent titles include a series of For Dummies guides to popular Nikon, Canon, and Olympus cameras. Other works include Digital Photography Before & After Makeovers, Digital Photo Projects For Dummies, Julie King's Everyday Photoshop For Photographers, Julie King's Everyday Photoshop Elements, and Shoot Like a Pro!: Digital Photography Techniques. When not writing, King teaches digital photography at such locations as the Palm Beach Photographic Centre.

An Ohio native and graduate of Purdue University, she now resides in West Palm Beach, Florida, and does not miss Midwestern winters even a little bit (although she very much misses friends who have not yet made the journey south).

Author's Acknowledgments

I am deeply grateful for the chance to work once again with the wonderful publishing team at John Wiley and Sons. Kim Darosett, Jennifer Webb, Steve Hayes, Barry Childs-Helton, and Sheree Montgomery are just some of the talented editors and designers who helped make this book possible. And finally, I am also indebted to technical

editor Scott Proctor, without whose insights and expertise this book would not have been the same.

Publisher's Acknowledgments

We're proud of this book; please send us your comments at http://dummies.custhelp.com. For other comments, please contact our Customer Care Department within the U.S. at 877-762-2974, outside the U.S. at 317-572-3993, or fax 317-572-4002.

Some of the people who helped bring this book to market include the following:

Acquisitions and Editorial

Senior Project Editor: Kim Darosett

Executive Editor: Steven Hayes

Senior Copy Editor: Barry Childs-Helton

Technical Editor: Scott Proctor

Editorial Manager: Leah Michael

Editorial Assistant: Leslie Saxman

Sr. Editorial Assistant: Cherie Case

Cover Photo: © iStockphoto.com / Maxim Bolotnikov

Cartoons: Rich Tennant (<u>www.the5thwave.com</u>)

Composition Services

Project Coordinator: Sheree Montgomery

Layout and Graphics: Carl Byers, Timothy Detrick,

Joyce Haughey, Christin Swinford

Proofreaders: Lindsay Amones, Melissa Cossell,

Rebecca Denoncour

Indexer: Infodex Indexing Services, Inc.

Publishing and Editorial for Technology Dummies

Richard Swadley, Vice President and Executive Group Publisher

Andy Cummings, Vice President and Publisher

Mary Bednarek, Executive Acquisitions Director

Mary C. Corder, Editorial Director

Publishing for Consumer Dummies

Kathleen Nebenhaus, Vice President and Executive Publisher

Composition Services

Debbie Stailey, Director of Composition Services

Introduction

Nikon. The name has been associated with top-flight photography equipment for generations. And the introduction of the D3200 has only enriched Nikon's well-deserved reputation, offering all the control a diehard photography enthusiast could want while at the same time providing easy-to-use, point-and-shoot features for the beginner.

In fact, the D3200 offers so *many* features that sorting them all out can be more than a little confusing, especially if you're new to digital photography, SLR photography, or both. For starters, you may not even be sure what SLR means or how it affects your picture taking, let alone have a clue as to all the other techie terms you encounter in your camera manual — *resolution, aperture, white balance,* and so on. And if you're like many people, you may be so overwhelmed by all the controls on your camera that you haven't yet ventured beyond fully automatic picture-taking mode. Which is a shame because it's sort of like buying a Porsche and never actually taking it on the road.

Therein lies the point of *Nikon D3200 For Dummies*. Through this book, you can discover not just what each bell and whistle on your camera does, but also when, where, why, and how to put it to best use. Unlike many photography books, this one doesn't require any previous knowledge of photography or digital imaging to make sense of things, either. In classic *For Dummies* style, everything is explained in easy-to-understand language, with lots of illustrations to help clear up any confusion.

In short, what you have in your hands is the paperback version of an in-depth photography workshop tailored specifically to your Nikon picture-taking powerhouse.

A Quick Look at What's Ahead

This book is organized into four parts, each devoted to a different aspect of using your camera. Although chapters flow in a sequence that's designed to take you from absolute beginner to experienced user, I've also tried to make each chapter as self-standing as possible so that you can explore the topics that interest you in any order you please.

Here's a brief preview of what you can find in each part of the book:

Part I: Fast Track to Super Snaps

Part I contains four chapters to help you get up and running. Chapter 1 offers a tour of the external controls on your camera, shows you how to navigate camera menus to access internal options, and walks you through initial camera setup. Chapter 2 explains basic picture-taking options, such as shutter-release mode and Image Quality settings, and Chapter 3 shows you how to use the camera's fully automatic exposure modes. Chapter 4 explains the ins and outs of using Live View, the feature

that lets you compose pictures on the monitor, and also covers movie recording.

Part II: Working with Picture Files

This part offers two chapters, both dedicated to after-the-shot topics. Chapter 5 explains how to review your pictures on the camera monitor, delete unwanted images, and protect your favorites from accidental erasure. Chapter 6 offers a look at some photo software options — including Nikon ViewNX 2, which ships free with your camera — and then guides you through the process of downloading pictures to your computer and preparing them for printing and online sharing.

Part III: Taking Creative Control

Chapters in this part help you unleash the full creative power of your camera by moving into the advanced shooting modes (P, S, A, and M). Chapter 7 covers the critical topic of exposure, and Chapter 8 explains how to manipulate focus and color. Chapter 9 summarizes all the techniques explained in earlier chapters, providing a quick-reference guide to the camera settings and shooting strategies that produce the best results for portraits, action shots, landscape scenes, and close-ups.

Part IV: The Part of Tens

In famous *For Dummies* tradition, the book concludes with two "top ten" lists containing additional bits of information and advice. Chapter 10 covers the most useful photo-editing tools found on the camera's Retouch menu, and Chapter 11 wraps up the book by detailing some camera features that, although not found on most "Top Ten Reasons I Bought My Nikon D3200" lists, are nonetheless interesting, useful on occasion, or a bit of both.

Icons and Other Stuff to Note

If this isn't your first *For Dummies* book, you may be familiar with the large, round icons that decorate its margins. If not, here's your very own icon-decoder ring:

A Tip icon flags information that will save you time, effort, money, or some other valuable resource, including your sanity. Tips also point out techniques that help you get the best results from specific camera features.

When you see this icon, look alive. It indicates a potential danger zone that can result in much wailing and teeth-gnashing if ignored. In other words, this is stuff that you really don't want to learn the hard way.

Lots of information in this book is of a technical nature — digital photography is a technical animal, after all. But if I present a detail that is useful mainly for impressing your technology-geek friends, I mark it with this icon.

I apply this icon either to introduce information that is especially worth storing in your brain's long-term memory or to remind you of a fact that may have been displaced from that memory by some other pressing fact.

Additionally, I need to point out these additional details that will help you use this book:

- ✓ **Other margin art:** Replicas of some of your camera's buttons and onscreen symbols also appear in the margins of some paragraphs. I include these to provide a quick reminder of the appearance of the button or feature being discussed
- ✓ **Software menu commands:** In sections that cover software, a series of words connected by an arrow indicates commands that you choose from the program menus. For example, if a step tells you to "Choose File⇒Convert Files," click the File menu to unfurl it and then click the Convert Files command on the menu.

Occasionally, I need to make updates to technology books. If this book does have technical updates, they will be posted at www.dummies.com/go/nikond3200updates.

eCheat Sheet

As a little added bonus, you can find an electronic version of the famous *For Dummies* Cheat Sheet at www.dummies.com/cheatsheet/nikond3200. The Cheat Sheet contains a quick-reference guide to all the buttons, dials, switches, and exposure modes on your D3200. Log on, print it out, and tuck it in your camera bag for times when you don't want to carry this book with you.

Practice, Be Patient, and Have Fun!

To wrap up this preamble, I want to stress that if you initially think that digital photography is too confusing or too technical for you, you're in very good company. *Everyone* finds this stuff a little mind-boggling at first. So take it slowly, experimenting with just one or two new camera settings or techniques at first. Then, each time you go on a photo outing, make it a point to add one or two more shooting skills to your repertoire.

I know that it's hard to believe when you're just starting out, but it really won't be long before everything starts to come together. With some time, patience, and practice, you'll soon wield your camera like a pro, dialing in the necessary settings to capture your creative vision almost instinctively.

So without further ado, I invite you to grab your camera, a cup of whatever it is you prefer to sip while you read, and start exploring the rest of this book. Your D3200 is

the perfect partner for your photographic journey, and I thank you for allowing me, through this book, to serve as your tour guide.

Please note that some special symbols used in this eBook may not display properly on all eReader devices. If you have trouble determining any symbol, please call Wiley Product Technical Support at 800-762-2974. Outside of the United States, please call 317-572-3993. You can also contact Wiley Product Technical Support at www.wiley.com/techsupport.

Part I Fast Track to Super Snaps



In this part . . .

Making sense of all the controls on your camera isn't something you can do in an afternoon — heck, in a week,

or maybe even a month. But that doesn't mean that you can't take great pictures today. By using your camera's point-and-shoot automatic modes, you can capture terrific images with very little effort. All you do is compose the scene, and the camera takes care of almost everything else.

This part shows you how to take best advantage of your camera's automatic features and also addresses some basic setup steps, such as adjusting the viewfinder to your eyesight and getting familiar with the camera menus, buttons, and other controls. In addition, chapters in this part explain how to obtain the very best picture quality, whether you shoot in an automatic or manual mode, and how to use your camera's Live View and movie-making features.



